



Post:

1. Take the posts out of the box and open out the legs.
2. Position them at a distance of approx. 2 m apart.




Wing:

Now fit the wings inbetween the posts at the desired height:



Wing A (narrow): glass dishes / table boards:

1. For the “glass stairs”, attach the wing at a tilt.
2. Fit 4 steel pins into the hole of the 1st, 2nd, 3rd and 4th rung, beginning from the bottom.
3. Place 4 glass dishes onto the wing.
4. For curved glass platters / table boards, attach the wing horizontally. Place platters / table boards onto.



Wing B (wide): Chafing dishes / table boards

1. Attach the wing horizontally.
2. Place end table board **a** and/or table board **b** onto, Chafing-Dishes **c** (without frame) into the wing.

 - Heatings / burner holder of the chafing dishes are attached directly at the water pan.
 - For electrical heater plugs, a plug board can be found under end table board **a**.

